

Lab Connection Instructions



1. Add **SmileDesign** to your lab list by calling 3M Customer Support at 1-800-634-2249. After the lab is set up, it must also be activated.
2. Enter new patient information
3. Scan patient
4. Review the scan quality, interocclusal clearance, and margins.
5. Select **SmileDesign**, No Models, and select material for restoration